

S E R V I C E N O T E

SUPERSEDES: NONE

4155C Semiconductor Parameter Analyzer

Serial Numbers: See below.

Firmware Update to Fix Whining Noise from CPU Board Beeper**Duplicate Service Notes:**

4155B-11 Serial Numbers: JP10E00593 / JP10E00909

4156B-11 Serial Numbers: JP10E00658 / JP10E01011

4155C-03 Serial Numbers: JP10J00100 / JP10J00261

4156C-03 Serial Numbers: JP10J00100 / JP10J00269

To be Performed by: Agilent-qualified personnel**Situation:**

The whining noise may be heard from the beeper on the CPU board. This problem may occur under the following conditions:

- Connecting printer by using parallel cable.
- The CPU board is 04155-69571.
- The firmware is HOSTC 03.01 or earlier

Continued

DATE: June 2001

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:					
MODIFICATION RECOMMENDED					
ACTION CATEGORY:	<input type="checkbox"/> IMMEDIATELY <input checked="" type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS:	LABOR 0.5 Hours		
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT	USED PARTS:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE		AGILENT RESPONSIBLE UNTIL: June 2003		
AUTHOR: TW	ENTITY: 3300	ADDITIONAL INFORMATION:			



Solution/Action:

Update the firmware to the HOSTC 03.02 and SMUC 04.02 by using the following procedure:

1. Go to the following location:

`ftp://hpyidmk.jp.agilent.com/dist/dc_para/4155C/firmware/HOSTC03.02/SMUC04.02/`

2. Save the 'h0302_s0402.zip' file to a local temporary directory. (Use the BINARY transfer mode to get the file.)
3. Extract directories and files from the 'h0302_s0402.zip' file, which is a 'zip' type compressed file. Four directories (disk1, disk2, disk3, and disk4) are created.
4. Copy the files in each directory to a 3.5-inch disk and label the disk. For example, after you have copied the files in the 'disk1' directory, label it "disk1".
5. Turn off the 4155B/56B/55C/56C. 6. Insert "disk1" into the 4155B/56B/55C/56C and turn on the 4155B/56B/55C/56C.
7. Press the {Yes} primary softkey to start the firmware update.
8. Replace the disks according to the displayed instructions. You use the disks in the following sequence:

disk1 -> disk 2 -> disk3 -> disk1 -> disk4

Note that "disk1" is used twice.

9. Wait until the update process completes.
10. Remove the disk and cycle the power.
11. Check the HOSTC and SMUC revisions on the [System]->{Config} page.

To do this update, 41501A,B SMU/PGU Expander is not necessary.