

4980A-02-S

S E R V I C E N O T E

SUPERSEDES: None

HP 4980A Network Advisor

Serial Numbers: 0000A00000 / 3121A00223

Duplicate Service Notes:

4981A-02-S
4982A-02-S

J2176A Mainframe Assembly

Modification To Meet HP Standards For Grounding

To Be Performed By: HP-Qualified Personnel

Parts Required

J2176-61602 Assy-Gnd Wire

Situation:

Instruments in the above serial number range have inadequate grounding of the rear panel to the mainframe chassis. This problem is being resolved with the addition of a grounding wire harness.

Solution:

Not all the instruments in the serial number range will require the ground wire. The instrument will need to be open up to see if the grounding wire is present. To inspect and/or add the rear panel grounding wire use the following procedures. Use the network advisor service manual for reference.

Continued

DATE: 08 October 1991

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
SAFETY			
ACTION CATEGORY:	<input type="checkbox"/> ON SPECIFIED FAILURE <input checked="" type="checkbox"/> AGREEABLE TIME	STANDARDS:	LABOR: 1.0 Hours
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input checked="" type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> HP LOCATION	SERVICE INVENTORY:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input checked="" type="checkbox"/> SEE TEXT
AVAILABILITY:	ALWAYS	USED PARTS:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input checked="" type="checkbox"/> SEE TEXT
AUTHOR: RCB	ENTITY: 3800	RESPONSIBLE ENTITY: 3800	UNTIL: ALWAYS
ADDITIONAL INFORMATION:			

© 1992 HEWLETT-PACKARD COMPANY
PRINTED IN U.S.A.



1. Place the network advisor on an ESD safe work area with the power cord disconnected.
2. Remove the network advisor top cover.

Note:

Look on the rear mounting screw of the hard drive shield, if there is a wire running to the external ports board the modification has already been completed. The service note is completed.

3. Remove the network advisor mainframe system board from the chassis.
4. Install the ground harness by performing the following steps:
 - 4a. Locate the TM1 terminal on the power supply board in the front left corner of the board and next to the TM2 terminal.
 - 4b. Attach the end of the grounding harness with the single eyelet to TM1.
 - 4c. Route and dress the grounding wire harness next to the AC power harness following it to the rear panel near the line module.
 - 4d. Attach one of the remaining eyelets of the grounding wire harness to the top left-hand mounting point on the rear panel external ports board.
 - 4e. Attach the remaining eyelet of the grounding wire harness to the rear chassis mounting point of the hard disk drive mounting bracket.
5. Put the system board back into the chassis.
6. Reassemble the top cover on to the chassis.
7. Once the network advisor is fully assembled, apply power. Some of the system setup information may have been lost when the battery was detached from the system board. Setup fields that may need to be reset are the time, the date and the hard disk drive type.

Drive types are: 52 MByte = type 41 105 MByte = type 42

A drive size label is located on the front edge of the hard disk drive. For the 52 MByte the label indicates "52AT" and "105AT" for the 105MByte drive.
8. Once the network advisor "setup" information has been restored, the unit should power up to the top level window.