

S E R V I C E N O T E

SUPERSEDES: NONE

E1671A SONET/SDH Transport Overhead Generator**Serial Numbers:** 0000A00000 / 9999Z99999**Clock jitter if external clock connected when internal clock selected.****To Be Performed By:** Customer**Situation:**

On all instruments, clock jitter will occur if the E1671A is used in the above configuration.

Solution/Action:

Either remove the external clock source or change the clock source selection on the E1671A to "External".

DATE:

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

DGH

ENTITY:

Y900

ADDITIONAL INFORMATION:

