S E R V I C E N O T E

SUPERSEDES: None

Agilent 85110A Pulse Test Sets

Noncompliance to a standard or regulation - required new fan guard

WARNING

Rear panel fan cutout and fan guard allow accessibility of fan blades to an IEC 61010 type test finger.

To Be Performed By: Customer

Duplicate Service Notes:

8510B-06-S

8510C-03-S

8511A-07-S

8511B-02-S

8514B-05-S

8515A-06-S

8517A-03-S

8517B-03-S

85110A-02-S

85110L-02-S

Continued

DATE: May 2001

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
SAFETY		
ACTION CATEGORY:	■ ON SPECIFIED FAILURE □ AGREEABLE TIME	STANDARDS: 1.0 Hours LABOR
LOCATION CATEGORY:	■ CUSTOMER INSTALLABLE □ ON-SITE □ SERVICE CENTER	SERVICE ☐ RETURN USED ☐ RETURN INVENTORY: ☐ SCRAP PARTS: ☐ SCRAP SEE TEXT
AVAILABILITY:	ALWAYS	AGILENT RESPONSIBLE UNTIL: ALWAYS
AUTHOR: LU	ENTITY: 5300	ADDITIONAL INFORMATION: PCO 53-62630

© 2001 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



Parts Required:

P/N Description Quantity

08517-60088 Finger guard bracket kit

Situation:

The configuration of the rear panel fan cutout and fan guard mounting allow enough room for an IEC 61010 type test finger to contact the cooling fan blades.

1

Solution / Action:

Finger Guard Bracket Kit to be installed onto the instrument.

- Step 1. Remove 2 screws and split lock washers along one side of the finger guard. Capture flat washers from between the finger guard and the grommet.
- Step 2. Slide 1 Bracket, Finger Guard (08517-00022) under the finger guard and align the 2 holes.
- Step 3. Install 2 screws (2360-0205) with 2 lock washers (2190-0017) and 2 grommets (0400-0002) into the 2 holes and torque to 10 in-lbs.
- Step 4. Remove remaining 2 screws, split lock washer and flat washers.
- Step 5. Install second bracket like the first on the opposite side of the finger guard, align holes.
- Step 6. Install 2 screws (2360-0205) and split lock washers (2190-0017) and torque to 10 in-lbs.
- Step 7. Inspect your work. Return instrument to use.

Please note: The design should contain a fan assembly with permanently attached threaded nuts. If the nuts are not permanently attached, it will be necessary to remove the top cover of the test set to allow dis-assembly and re-assembly while holding the hex nuts on the inside of the test set.