

S E R V I C E N O T E

SUPERSEDES: None

4396B Network/Spectrum/Impedance Analyzer

Serial Numbers: 4396B: JP1KE00387 / JP1KE00421

Use of GSP PN E4970-66552 and LCD PN 2090-0574 may cause a display problem**To Be Performed By:** Agilent-Qualified Personnel**Parts Required:**

P/N	Description	Quantity
E4970-66554	GSP	1

Situation:

An intermittent display problem (all white image is displayed continuously) may happen after power on. The configuration of old GSP Board PN E4970-66552 and LCD PN 2090-0574 may cause this problem.

Solution / Action:

When the GSP board with P/N E4970-66552 becomes defective, P/N E4970-66554 must be used to replace it.

DATE: July 1998

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

ENTITY:

ADDITIONAL INFORMATION:

IT

3355