

## S E R V I C E N O T E

SUPERSEDES: None

**85462A EMI Receiver RF Section**

Serial Numbers: 0000A00000 / 9999Z99999

**Shipment Instruction Label**

Duplicate Service Notes: 85422E-08

To Be Performed By: Agilent-Qualified Personnel  
Customer**Parts Required:**

P/N	Description	Quantity
7121-7828	Caution Label	1

**Situation:**

Some 85462A's and 85460A's incur shipping damage because they are not being separated prior to shipment and are not being shipped in in separate containers.

**Solution/Action:**

Affix the caution label (P/N 7121-7828) to the top of the 85462A. This label reads "Caution! For shipping purposes: If an RF Filter Section is present, disconnect the two systems components and ship in a separate container or damage may result!".

The label should be affixed to the top of the 85462A over, centered on the front frame. It should be readable from the front of the instrument. It may be placed on the instrument upon customer request, or when the instrument is returned to the CSC for repair or calibration.

DATE: June 1999

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
<b>MODIFICATION AVAILABLE</b>		
ACTION CATEGORY:	AGREEABLE TIME	<input type="checkbox"/> PERFORMANCE ENHANCEMENT <input checked="" type="checkbox"/> SERVICE/RELIABILITY ENHANCEMENT
LOCATION CATEGORY:	<input checked="" type="checkbox"/> CUSTOMER INSTALLABLE <input checked="" type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	AVAILABLE UNTIL: Product Support Life
AUTHOR: LPW	ENTITY: 5340	ADDITIONAL INFORMATION: