

UXR0334A-02

Modification Recommended Service Note

Supersedes:
NONE

UXR0334A Infiniium UXR-Series Oscilloscope: 33 GHz, 4 Channels

Serial Numbers: MY58310101, MY58310102, MY58310107, MY58310108, MY58310111, MY58310113, MY58310115, MY58310117, MY58310119, MY58310123, MY58310124, MY58310125, MY58310128, MY58310132, MY58310136, MY58310137, MY58310138

The Problem, acquisition board has cracks with the P2000 connector that mates to the channel module.

Parts Required:

P/N	Description	Qty.
54964-69702	Refurbished, Production calibrated acquisition assembly, Exch	2
If refurbished is not available use;		
54964-68702	Acquisition assembly	2

ADMINISTRATIVE INFORMATION

ACTION	X ON SPECIFIED FAILURE	STANDARDS			
CATEGORY:	<input type="checkbox"/> AGREEABLE TIME	LABOR:	1.0 Hours		
LOCATION	<input type="checkbox"/> CUSTOMER INSTALLABLE	SERVICE:	X RETURN	USED	<input type="checkbox"/> RETURN
CATEGORY:	<input type="checkbox"/> ON-SITE (active On-site contract required)	INVENTORY:	<input type="checkbox"/> SCRAP	PARTS:	<input type="checkbox"/> SCRAP
	X SERVICE CENTER		<input type="checkbox"/> SEE TEXT		<input type="checkbox"/> SEE TEXT
	<input type="checkbox"/> CHANNEL PARTNERS				
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL:	August 01, 2022		
	X Calibration Required	PRODUCT LINE:	PL1A		
	<input type="checkbox"/> Calibration NOT Required	AUTHOR:	MR		

ADDITIONAL INFORMATION:

Situation:

If the unit is listed in the serial numbers above, then we want to proactively replace the two acquisition boards if the unit is returned for any repair problem.

Solution/Action:

Replace both acquisition boards. Use the internal service guide for the details on the process to do so.

Revision History:

Date	Service Note Revision	Author	Reason for Change
29 August 2019	01	Mark Rowley	As Published